Aluminium Stair Tread Installation

- 1. Slide bolts into channels and align tread as required
- 2. Place washers onto bolt and tighten nut to fix. Repeat for both sides.
- 3. Fit Step end covers using the screws provided





