


# EASY SCREEN



**INSTALLATION GUIDE** 

### **EASY SCREEN SPECIFICATIONS**



Max width 2000mm

#### **SLAT OR LOUVER\***

(PART A) Blades 76x16x1994mm

**(PART B)** FrictionFit Slat End Rails 28x27x2000mm (Rails and Blades can be cut to fit the size you require)

\*For louver screens you will also need Louver Adaptors

Endrails are also available to suit composite or hardwood slats

Fixing Options

Easy Screen Brackets – 25x20 angle x 80mm – packs of 4
Easy Screen Fixing Channel – 2000mm lengths.
(Increased stability and neater fixing compared to brackets)

#### **BLADE CALCULATOR**

The calculator shows at a glance the number of blades required to fit maximum height 2000mm.

| Height<br>in mm | PART A<br>76x16mm          | COMPOSITE<br>67x15mm       | HARDWOOD<br>90x19mm     |
|-----------------|----------------------------|----------------------------|-------------------------|
| 2000-           | 20                         | 22                         | 18 2000                 |
| 1750-           | 18                         | 20                         | 16 - 1750               |
| 1500-           | 16                         | 18                         | 14 - 1500               |
| 1250-           | 14                         | 16                         | 12 - 1250               |
| 1000-           | No. of blades required: 10 | No. of blades 12 required: | No. of blades required: |
| 750 -           | 8                          | 10                         | 8 - 750                 |
| 500 -           | 6                          | 6                          | - 500                   |
| 250 -           | 2                          | (4)                        | 2 - 250                 |
| 0               |                            |                            |                         |







## **HOW TO ASSEMBLE YOUR EASY SCREEN**

Tools Required: Pencil, String-line, Tape Measure, Spirit Level, Drill, Tek Gun/Drill, Angle Grinder with steel cutting disc

#### SLAT

- Cut Blades (Part A) and End Rails (Part B) to required lengths.
- Position End Rail on the ground against a wall with a soft padding. Push fit the Blades into end rail ensuring a good friction fit, tap with a mallet if required.
- 3. Elevate assembly on 2 padded bearers to allow second side frame to be attached. Starting at one end work slats into side frame 1 at a time.
- Once slats are inserted tap side frame until all the slats are fully engaged.





As above but insert louver adaptors into both ends of Blades (Part A) prior to step 2.



# **HOW TO INSTALL YOUR EASY SCREEN**

Before fixing screen in place, measure diagonals to ensure it is square.

# Between posts or to side of wall

- Use either easy screen fixing channel or fixing brackets to fix screen to posts.
- 2. Cut fixing channel to same height as
- Fit easy screen brackets or screw fixing channel every 500mm approx



# **CUSTOM SERVICE AVAILABLE**

Window awning brackets are available from the Special Orders Desk.

If you are looking for a different size or colour to the off the shelf range, we can custom manufacture screens in any dimension and colour you require.

Visit Bunnings Warehouse Special Orders Desk for further information on how to order.



